




TIME SETTING



Note: Time setting should be done clockwise to synchronise minute/ hour hand.
If done anti-clockwise hour/ minute hands will not be synchronised.